

MORRIS MINOR CONV TOP COVER INSTALLATION

Convertible top covers attach only to two lift-the-dot studs at their rearward edge and two lift-the-dot studs at the rear of the side quarterglass. There is no attachment inside the cockpit on their forward edge. The rear lift-the-dot studs are located just outboard of the trunk hinges by 1-2 inches.

At the bottom edge of the pocket that fits over the folded frame arms, two plain snaps hold the pocket together, much like a shirt cuff over your wrist. These plain snaps do not attach to the cockpit, just to the other side of the cover to form the pocket.

It appears both Series 2 and 1000 use this arrangement, however in the Series MM drivers handbook, three plain snaps are shown at the pocket area, one more behind the two pictured.

